

GENERAL

TERMS OF USE OF NEW MATERIALS - PLEASE READ CAREFULLY

From time to time, Enfora, in its sole discretion, may make available for download on its website (www.enfora.com), or may transmit via mail or email, updates or upgrades to, or new releases of, the firmware, software or documentation for its products (collectively, 'New Materials'). Use of such New Materials is subject to the terms and conditions set forth below, and may be subject to additional terms and conditions as set forth in Enfora's Technical Support Policy (posted on its website) and/or any written agreement between the user and Enfora.

All New Materials are provided AS IS. Enfora makes no warranty or representation with respect to the merchantability, suitability, functionality, accuracy or completeness of any such New Materials. The user of such New Materials assumes all risk (known or unknown) of such use. Enfora reserves all rights in such New Materials. The user shall have only a revocable and limited license to use such New Materials in connection with the products for which they are intended. Distribution or modification of any New Materials without Enfora's consent is strictly prohibited.

IN NO EVENT WILL ENFORA BE RESPONSIBLE FOR ANY INCIDENTAL, INDIRECT, CONSEQUENTIAL OR SPECIAL DAMAGES AS A RESULT OF THE USE OF ANY NEW MATERIALS. ENFORA'S MAXIMUM LIABILITY FOR ANY CLAIM BASED ON THE NEW MATERIALS SHALL NOT EXCEED FIFTY U.S. DOLLARS (\$50).

COPYRIGHT

© 2009 Enfora, Inc. All rights reserved. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording or otherwise), or for any purpose, without the express written permission of Enfora, Inc.

Enfora and the Enfora logo are either registered trademarks or trademarks of Enfora, Inc. in the United States.

251 Renner Pkwy
Richardson, TX 75080 USA
972-633-4400
Phone: (972) 633-4400
Fax: (972) 633-4444
Email: info@enfora.com
www.enfora.com

LIMITED WARRANTY

SCOPE

Enfora warrants to the original purchaser of the product that, for a period of one (1) year from the date of product purchase, the product hardware, when used in conjunction with any associated software (including any firmware and applications) supplied by Enfora, will be free from defects in material or workmanship under normal operation. Enfora further warrants to such original purchaser that, for a period of ninety (90) days from the date of product purchase, any software associated with the product will perform substantially in accordance with the user documentation provided by Enfora, and any software media provided with the product will be free from defects in material or workmanship under normal operation. Enfora does not warrant that (a) the product hardware or any associated software will meet the purchaser's requirements, (b) that the operation of the product hardware or software will be uninterrupted or error-free, or (c) the product, when integrated in, or combined with, other products or software not supplied by Enfora, will continue to perform substantially in accordance with the user documentation. This limited warranty is only for the benefit of the original purchaser and is not transferable. No other party may act on behalf of such purchaser for the purpose of claiming or exercising any rights or benefits under or in connection with this limited warranty except as may be provided in a written agreement between Enfora and such other party.

HARDWARE

During the warranty period applicable to the product hardware, Enfora, at its expense and in its sole discretion, will repair or replace the product if it is determined to have a covered hardware defect, provided that the purchaser first notifies Enfora of any such defect, furnishes Enfora with a proof of purchase, requests and obtains a return merchandise authorization (RMA) number from Enfora, and returns the product, shipping charges prepaid, to Enfora under that RMA. If, upon reasonable examination of the returned product, Enfora does not substantiate the defect claimed by purchaser, or determines that the defect is not covered under this limited warranty, Enfora will not be required to repair or replace the product, but may instead reship the product to the purchaser, in which case purchaser shall be responsible for paying Enfora's usual charges for unpacking, testing, and repacking the product for reshipment to purchaser. Purchaser shall bear the risk of loss or damage in transit to any product returned by purchaser to Enfora, or any returned product not found to be defective or covered under this warranty and reshipped by Enfora to purchaser. In the event Enfora repairs or replaces a defective product, the repaired or replacement product will be covered under this limited warranty for the remainder of the original warranty period on the defective product. If Enfora is unable to repair or replace a defective product, the purchaser's exclusive remedy shall be a refund of the original purchase price. Any returned and replaced product, or any product for which Enfora has refunded the original purchase price, becomes the property of Enfora.

SOFTWARE

During the warranty period applicable to the software or its media, Enfora, at its expense, will replace any defective software or media if purchaser gives written notification of the defect to the technical support department at Enfora during the applicable warranty period. Enfora will ship or otherwise transmit the replacement software or media to purchaser, and purchaser shall be responsible for incorporating any replacement software in the product. Enfora shall not have any obligation to provide any software bug fixes, upgrades or new releases except as may be necessary to correct any covered defect of which purchaser notifies Enfora in writing during the applicable warranty period. Enfora, from time to time and in its sole discretion, may make available for download on its website (www.enfora.com) certain software bug fixes, upgrades or new releases for the product. The purchaser should periodically visit such website to determine whether any such bug fixes, upgrades or new releases have become available. Download and use of any such bug fixes, upgrades or new releases is subject to all of the applicable terms and conditions of Enfora's technical support policy as posted and updated on its website.

EXCEPTIONS AND DISCLAIMERS

Enfora shall have no obligation under this limited warranty for (a) normal wear and tear, (b) the cost of procurement of substitute products or (c) any defect that is (i) discovered by purchaser during the warranty period but purchaser does not notify or request an RMA number from Enfora, as required above, until after the end of the warranty period, (ii) caused by any accident, misuse, abuse, improper installation, handling or testing, or unauthorized repair or modification of the product, (iii) caused by use of any software other than any software supplied by Enfora, or by use of the product other than in accordance with its documentation or (iv) the result of electrostatic discharge, electrical surge, fire, flood or similar causes. Unless otherwise provided in a written agreement between the purchaser and Enfora, the purchaser shall be solely responsible for the proper configuration, testing and verification of the product prior to deployment in the field.

ENFORA'S SOLE RESPONSIBILITY AND PURCHASER'S SOLE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE TO REPAIR OR REPLACE THE PRODUCT HARDWARE, SOFTWARE OR SOFTWARE MEDIA (OR IF REPAIR OR REPLACEMENT IS NOT POSSIBLE, OBTAIN A REFUND OF THE PURCHASE PRICE) AS PROVIDED ABOVE. ENFORA EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, SATISFACTORY PERFORMANCE AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ENFORA BE LIABLE FOR ANY INDIRECT, SPECIAL, EXEMPLARY, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOSS OR INTERRUPTION OF USE, DATA, REVENUES OR PROFITS) RESULTING FROM A BREACH OF THIS WARRANTY OR BASED ON ANY OTHER LEGAL THEORY, EVEN IF ENFORA HAS BEEN ADVISED OF THE POSSIBILITY OR LIKELIHOOD OF SUCH DAMAGES.

OTHER CONSIDERATIONS

Some jurisdictions may require a longer warranty period than specified above and, accordingly, for products sold in those jurisdictions the applicable warranty period shall be extended as required under the laws of those jurisdictions. Furthermore, some jurisdictions may not allow the disclaimer of implied warranties or the exclusion or limitation of incidental or consequential damages, so the above disclaimer, limitation or exclusion may not apply to products sold in those jurisdictions. This limited warranty gives the purchaser specific legal rights and the purchaser may have other legal rights that vary from jurisdiction to jurisdiction.

In some instances, certain aspects of the product warranty may also be covered in a separate written agreement between Enfora and the distributor or reseller, if any, from whom purchaser purchased the product. That agreement may provide, for example, a different product return procedure that may also be available to purchaser (e.g., the product may be returned to Enfora through that distributor or reseller).

OTHER CONSIDERATIONS

This limited warranty shall be governed by the laws of the State of Texas, United States of America, without regard to conflict of laws principles. This limited warranty shall not be governed in any respect by the United Nations Convention on Contracts for the International Sale of Goods.

REGULATORY COMPLIANCE

FCC

The modem was tested and certified to meet FCC Parts 15 in a stand-alone configuration, which demonstrated that the GSM1308 and GSM1318 SA-G+ complies with Part 15 emission limits. FCC Part 22 & Part 24 is covered by the Enfora Enabler-III "modular approval" process for a transmitter. This approach, described by FCC Public Notice DA 00-131407 released June 26, 2000, is intended to afford relief to equipment manufacturers by eliminating the requirement for obtaining a new equipment authorization for the same transmitter when installed in a new device.

In order to use the GSM1308 and GSM1318 SA-G+ without additional FCC certification approvals, the installation must meet the following conditions:

- A separation distance of at least 20 cm (7.87 inches) between the antenna and the body of the user and other persons must be maintained at all times.
- GSM 850 mode: With the maximum conducted power at 32 dBm, the maximum antenna gain is 4.5 dBi (2.35 dBd) in order to meet maximum 7 watt ERP for mobile transmitters and MPE (Maximum Permissible Exposure) requirement of General Population/Uncontrolled exposures.
- GSM 1900 mode: With the maximum conducted power at 31dBm, the maximum antenna gain is 2 dBi in order to meet maximum 2 watt EIRP for

mobile transmitters and MPE (Maximum Permissible Exposure) requirement of General Population/Uncontrolled exposures.

RF EXPOSURE

Your GSM1308 or GSM1318 SA-G+ modem is a radio transmitter and receiver. It is designed and manufactured not to exceed the emissions limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. These guidelines are based on the safety standards previously set by the U.S. and international standards bodies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless RF devices, such as the GSM1308 and GSM1318 SA-G+ modem, employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. SAR values at or below that limit are considered safe for the general public.

Before a wireless RF device is made available for sale to the Public, it must be tested and certified to the FCC that it does not exceed the SAR limits established by the FCC. Tests for SAR are conducted using the positions and locations (e.g., at the ear or worn on the body) as required by the FCC for each device model. The Spider AT has been tested and meets the FCC RF exposure guidelines when used against the body under normal usage conditions.



The GSM1308 and GSM1318 SA-G+ modem has been fully tested and complies with all the requirements of EN301 489-1, EN301 489-7 and EN60950-1:2001. Compliance to EN 301 511 has been demonstrated by testing on both the GSM1308 and the integrated GSM0308 module. At the separation distance of at least 20 cm (7.87 inches) between the antenna and the body of the user and other persons, the product also meet EN50392 MPE requirement.

DISCLAIMER

The information and instructions contained within this publication comply with all FCC, GCF, PTCRB, R&TTE, IMEI and other applicable codes that are in effect at the time of publication. Enfora disclaims all responsibility for any act or omissions, or for breach of law, code or regulation, including local or state codes, performed by a third party.

Enfora strongly recommends that all installations, hookups, transmissions, etc., be performed by persons who are experienced in the fields of radio frequency technologies. Enfora acknowledges that the installation, setup and transmission guidelines contained within this publication are guidelines, and that each installation may have variables outside

of the guidelines contained herein. Said variables must be taken into consideration when installing or using the product, and Enfora shall not be responsible for installations or transmissions that fall outside of the parameters set forth in this publication.

TABLE OF CONTENTS

General	1
COPYRIGHT	1
LIMITED WARRANTY	2
SCOPE	2
Hardware	2
SOFTWARE	3
EXCEPTIONS AND DISCLAIMERS	3
OTHER CONSIDERATIONS	4
REGULATORY COMPLIANCE.....	4
FCC	4
RF EXPOSURE.....	5
R&TTE 	5
Table of Contents.....	7
Table of Figures.....	8
Table of Tables.....	8
1 Introduction	1
1.1 About the GSM/GPRS SA-G+	1
1.2 About this Manual	1
1.2.1 Manuals	1
1.2.2 Application Notes	1
1.2.3 Technical Notes.....	2
1.3 System Requirements	2
1.4 SA-G+ Front and Back View.....	3
2 Installation	4
2.1 Subscriber Identity Module (SIM) Card.....	4
2.2 Eight (8) Pin Connector.....	5
2.2.1 GPIO1 (Input/Output).....	7
2.2.1.1 GPIO 1 Electrical Specifications.....	7
2.2.1.2 GPIO1 as an Input.....	7
2.2.1.3 GPIO1 as an Output.....	7

2.2.2	GPIO2 (Input/Output) Programmable Pull-Up System	8
2.2.2.1	GPIO 2 Electrical Specifications	8
2.2.2.2	GPIO2 as Pull-Down System	8
2.2.2.3	GPIO2 as a Pull-Up System.....	8
2.3	Connecting the Serial Cable	10
2.4	Connecting the GSM/GPRS Antenna	11
2.5	LED Functions.....	12
2.6	Mounting the SA-G+	12
3	Firmware Upgrade.....	13
4	Configure the Computer and Verify Correct Communications	14
5	Configure the SA-G+ to talk to the Enfora Server	20
6	Verifying Server Connectivity.....	26
7	Tech Support	28

TABLE OF FIGURES

Figure 1 - Front view of GSM/GPRS SA-G+ modem.....	3
Figure 2 - Rear view of GSM/GPRS SA-G+ modem.	3
Figure 3 - Inserting a SIM Card in a GSM/GPRS SA-G+ Module.....	4
Figure 4 Molex Connector and Pins	7
Figure 5- Serial Pin-out.....	10
Figure 6 GSM/GPRS SA-G+ Connecting the Antenna	11
Figure 7 Mounting Dimensions	12

TABLE OF TABLES

Table 1 Cable Assembly Parts.....	5
Table 2 8 pin I/O Connector Interface	6
Table 3 GSM Operating Power.....	9
Table 4 REG LED Behavior During Firmware Upgrade	13

I Introduction

I.1 ABOUT THE GSM/GPRS SA-G+

The GSM/GPRS SA-G+ is a compact, stand-alone wireless IP (GSM/GPRS) modem. The GSM/GPRS SA-G+ is designed for computing devices operating Windows XP and Windows 2000 or any serial-enabled platform. The SA-G+ can be used as a stand-alone serial device with other vertical applications. Enfora's GSM/GPRS SA-G+ provides maximum versatility in a single affordable device with 2 User-Definable Input/Outputs (I/O) and 1 User-Definable Output.

I.2 ABOUT THIS MANUAL

Contained in this manual are instructions on how to install and configure the GSM/GPRS SA-G+ modem. Please follow the instructions herein closely to avoid damaging the GSM/GPRS SA-G+.

The GSM/GPRS SA-G+ modem contains an Enfora Enabler-IIIIG OEM module. Detailed information pertaining to the specifications and operation of the module will pertain, in part, to the GSM/GPRS SA-G+ platform.

The information can be accessed at the Enfora website (<http://www.enfora.com>) under Support and Resources.

Refer to the following documentation for additional information, if required:

I.2.1 MANUALS

GSM0308AT001 - Enfora IIIIG Module AT Command Set Reference

GSM0308UG001 - Enfora GSM-GPRS Family API Reference

I.2.2 APPLICATION NOTES

GSM0000AN002 - Enabler-G PPP Configuration for Windows 2000

GSM0000AN003 - Enabler-G Data Circuit Switched Call Configuration and Use

GSM0000AN004 - Enabler-G SMS Configuration and Use

GSM0000AN005 - Enabler-G Automated Network Connection Configuration and Use

GSM0000AN006 - Enabler-G Module Status Query

GSM0000AN007 - Enabler-G Status Reporting

GSM0000AN008 - Enabler-G PPP Configuration for Windows XP

GSM0000AN009 - Dynamic IP Assignment Support
GSM0000AN011 - PAD Configuration and Use
GSM0000AN012 - Network Transparency Configuration for PAD
GSM0000AN013 - Enabler-G Sleep Mode Configuration and Use
GSM0000AN014 - Anytime PPP API Access
GSM0000AN015 - Event Monitor and Reporting Overview
GSM0000AN016 - How to Send SMS Messages to an E-Mail Address
GSM0000AN017 - SMTP Mail Access via TCP PAD
GSM0000AN018 - USNO NTP Network Time Service TCP PAD
GSM0000AN019 - Network Configuration Worksheet
GSM0000AN020 - Comparison of Modem Power Control Pins in Enfora Modules
GSM0000AN022 - Sending AT Commands over SMS
GSM0000AN023 - Configure the Modem to talk to the Enfora Server
GSM0000AN024 - Enhanced Test Mode Commands
GSM0000AN025 - Enabler IIG Network Personalization
GSM0000AN026 - Using a Terminal Program to Test PAD
GSM0000AN027 - AT\$ACTIVE Command Implementation Behavior

I.2.3 TECHNICAL NOTES

GSM0000TN001 - Enabler-G Firmware Upgrade
GSM0000TN002 - Enabler-G PPP Negotiation Sequence
GSM0000TN006 - UDP Wakeup Message Header Decoding
GSM0000TN007 - Enabler-G 3-Wire Serial Interface Requirements
GSM0000TN009 - Server Application Design Considerations for Dynamic IP
GSM0000TN012 - Engineering Mode Manual

I.3 SYSTEM REQUIREMENTS

- Windows XP and Windows 2000 operating systems or other serial-enabled platform.
- One standard RS-232 serial port for GSM/GPRS SA-G+ configuration.

I.4 SA-G+ FRONT AND BACK VIEW



Figure 1 - Front view of GSM/GPRS SA-G+ modem.



Figure 2 - Rear view of GSM/GPRS SA-G+ modem.

2 Installation

2.1 SUBSCRIBER IDENTITY MODULE (SIM) CARD

The SIM, an integral part of any GSM terminal device, is a “smart card” that is programmed with subscriber information. The user information consists of an International Mobile Subscriber Identity (IMSI) number, which is registered with the GSM service provider, and an encryption Ki (pronounced “key”). This information consists of a microprocessor and memory installed on a plastic card. To install the SIM card into the modem, insert the SIM card in the modem as shown below in Figure 3.



Note: The SIM is not provided with the SA-G+ modem. The SIM must be obtained from the GSM service provider and must be provisioned by the operator for data and/or voice. Always take care to protect the SIM: the GSM terminal will not operate without the SIM installed.

Insert the SIM card here – please note that the notch must be in the upper left hand corner.



After inserting the SIM card, you MUST move the SIM lock switch to the left. If the lock is open, there will not be power to the SIM.

Figure 3 - Inserting a SIM Card in a GSM/GPRS SA-G+ Module

2.2 EIGHT (8) PIN CONNECTOR

The GSM/GPRS SA-G+ modem can utilize input power ranging from 6 Vdc to 40 Vdc. If your unit did not include an optional power supply, or if you wish to configure a separate power interface, the following connector parts are the Enfora recommended parts that can be used to mate with the existing modem power connector:



<p>Connector: Manufacturer: Molex Part Number: 43025-0800</p>	
<p>Pins: Manufacturer: Molex Part Number: 43030-0008 20-24 AWG 43030-0011 26-30 AWG</p>	
<p>Crimp Tool: Manufacturer: Molex Part Number: 63811-2800</p>	

Table 1 Cable Assembly Parts

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



During installation take precautions to help ensure proper operation of the SA-G+. Do not create loops, sharp bends or crimps in the cables. Use proper terminations on all power cables.



Note: : If the SA-G+ will be used in a vehicle, attach all cables to the vehicle and equipment in such a way to reduce stress or wear caused by vibration generated by moving vehicles.

The user can purchase the optional eight (8) pin external I/O connector for the Enfora SA-G+ that can be used to interface with other devices. Enfora can provide an optional cable and connector (Part #CAB1308). The user also has the option of building his/her own cable. Table 2 describes the pin functionality for this 8 pin I/O connector. Pins that are not planned for usage can be left open without anything connected to them.

Pin Number	Functionality	Description
Pin – 1	Microphone +	
Pin – 2	Headset +	
Pin – 3	Ground	
Pin – 4	Ground	
Pin – 5	Supply Voltage	(6-40V)
Pin – 6	User Controlled IO1	(3.3 – 40V) – Uses GPIO1 of the Enabler IIIG Module
Pin – 7	User Controlled IO2	(3.3 – 40V) – Uses GPIO6 of the Enabler IIIG Module
Pin – 8	User Controlled Output	(1.5A sink) – Uses GPIO8 of the Enabler IIIG Module. This GPIO's state is latched during a reset.

Table 2 8 pin I/O Connector Interface




Figure 4 Molex Connector and Pins

2.2.1 GPIO1 (INPUT/OUTPUT)

2.2.1.1 GPIO1 ELECTRICAL SPECIFICATIONS

- Input VIH: >2.2 V
- Input VIL: <1 V
- Output VOH: 3 V
- Output VOL: 0
- Max Source Current: Approximately 350 μ A
- Max Sink Current: 3.7 mA @ 40 V, 0.13 W

2.2.1.2 GPIO1 AS AN INPUT

Set the bus direction to be “input” by using the “AT\$IOGP1=1” command.

Verify that GPIO1 is set to be an input by using the “AT\$IOCFG?” command.

2.2.1.3 GPIO1 AS AN OUTPUT

Change GPIO1 to be an output by using the “AT\$IOCFG=xxx” command.

Set the bus direction to be an output by using the “AT\$IOGP1=0” command.

2.2.2 GPIO2 (INPUT/OUTPUT) PROGRAMMABLE PULL-UP SYSTEM

2.2.2.1 GPIO 2 ELECTRICAL SPECIFICATIONS

- Input VIH: >2.2 V
- Input VIL: <1 V
- Output VOH: 3 V
- Output VOL: 0
- Max Source Current: Approximately 320 μ A
- Max Sink Current: 3.7 mA @ 40 V, 0.13 W

2.2.2.2 GPIO2 AS PULL-DOWN SYSTEM

Set GPIO2 to 0 by using the “AT\$IOPULUP=0” command.

2.2.2.3 GPIO2 AS A PULL-UP SYSTEM

Set GPIO2 to 1 by using the “AT\$IOPULUP=1” command.

*Set the bus direction as described in 3.2.1 using the AT\$IOP2=x command where x is 0 or 1..

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



The following table provides the power characteristics of the GSM/GPRS SA-G+ modem.

Band	Mode	Avg (mA)	Peak (A@dBm)
GSM 850	1 TX/1 RX	200	1.30@33
EGSM 900	Idle	50 DRX 5	
DCS 1800	1 TX/1 RX	160	0.92@30
PCS 1900	Idle	50 DRX 5	
	Sleep	20	

Table 3 GSM Operating Power



Warning: Use of the device outside of the specified voltage range may result in damage to the device and/or undesirable results.

2.3 CONNECTING THE SERIAL CABLE

To connect the SA-G+ with a local computing device, connect one end (male end) of the 9-wire RS232 Serial Cable to the SA-G+ port labeled "Serial" and connect the other end to a computer.

The following figure provides the SA-G+ serial pin-out information.




Figure 5- Serial Pin-out

2.4 CONNECTING THE GSM/GPRS ANTENNA

The antenna is supplied by the user. The antenna must have a nominal impedance of 50 Ohms. The VSWR must be less than 2.0:1. System antenna gain should be 0-2 dB for optimum performance.

The GSM/GPRS SA-G+ operates at the 850/900/1800 and 1900 MHz frequency bands. Care needs to be taken when connecting the antenna since the right type of antenna will be required for proper operation of the modem. The antenna connector on the GSM/GPRS SA-G+ modem is SMA Female. The antenna has to be connected to the connector labeled “Antenna” as shown below in Figure5.



Figure 6 GSM/GPRS SA-G+ Connecting the Antenna

2.5 LED FUNCTIONS

The GSM/GPRS SA-G+ modem has one green LED on the front panel.

REG: Indicates GSM network registration status. Flashing when attempting to register on a GSM network. Solid when the modem is registered with a GSM network.

2.6 MOUNTING THE SA-G+

The GSM/GPRS SA-G+ includes two mounting options. The modem housing contains four thru holes that can utilize number 2 screws for securing the device. The other option available is the inclusion of four threaded holes for securing screws to be used to secure the device.




Figure 7 Mounting Dimensions

3 Firmware Upgrade

To see if there is updated firmware for the SA-G+, please visit:

<http://www.enfora.com> > support

You will need to obtain a login to the website from Enfora Tech Support in order to download the firmware.

During the firmware upgrade, the LED's will display the following behavior:

	SIM Installed (registered with network)	SIM Not Installed (registering with network, LED is on)	SIM Not Installed (registering with network, LED is off)
REG LED	Solid		
Behavior		Solid	
			Off

Table 4 REG LED Behavior During Firmware Upgrade

4 Configure the Computer and Verify Correct Communications



Note: The following examples use Windows 2000 and HyperTerminal. Any Terminal program should work, using the parameters in Step 1

1. Default Serial Parameters

- a. Autobaud (power up message at 115200 baud rate)
- b. 8 data bits
- c. 1 stop bit
- d. No Parity
- e. Flow Control = None

2. Determine which Com port to use


- f. On older computers, there is usually a built in Com port. This is normally Com1.
- g. If you are using a USB-to-serial converter, you will need to determine which Com port it is installed on.




Note: If the USB-to-serial converter has not been installed, install the necessary drivers per the instruction supplied by your USB-to-Serial device. Then leave the device unplugged.

- h. Open up the System Properties window. This is done through the Control Panel > System or right-click on My Computer and select Properties. Select the Hardware Tab. On Windows 2000 the screen looks like the following:

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**




- i. Select the Device Manager button. Expand the Ports section by selecting the + sign beside Ports. Your window should look like the following:



**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



- j. Plug in the USB-to-Serial converter. The window should change to show the USB-to-Serial converter installed.



- k. Most devices will show the Com port next to the device name. Record this number. In this case, it is COM12.



Note: Make sure there is no "!" or "X" next to the USB device. If you see an "!" or an "X," the device is not properly installed and will not work

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



3. Start HyperTerminal

On Windows 2000, click on:

Start>Programs>Accessories>Communications>HyperTerminal


- I. You should see the following screen.



- m. Enter a name for the Connection. In this example, the Name is Enfora Com1.
- n. Click OK.
- o. The next window that will appear is the Connect To window.




- p. Change the Connect Using setting to the Com port that was determined in Step B.
- q. Click OK.
- r. The next window is the Port Settings window.



**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



- s. Make sure the settings match the example.
- t. Click OK.
- u. Now the Main Program Window should appear.



5 Configure the SA-G+ to talk to the Enfora Server

4. Connect and verify Serial connectivity with the Enfora SA-G+.
 - v. Connect the PC serial connector to the SA-G+ serial port.




Note: In the following instructions, <CR> means using the Enter Key on the keyboard

With HyperTerminal open, hit the Enter key. The SA-G+ should respond with OK. If you do not see this response, double-check your connections.

- w. Type AT<CR>. The SA-G+ should respond with OK. If you do not see the letters AT, send the following command to the SA-G+: ATE1<CR>
- x. Type ATI<CR>. The SA-G+ should respond with Enfora, Inc. If you get any different response, you are not connected to the Enfora SA-G+.

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



5. Configure the SA-G+ to communicate with the Enfora Test Server.
 - y. The following information will need to be obtained from the SIM provider. Please refer to GSM0000AN019 – Network Configuration Worksheet.
 - z. APN
 - aa. Username and password (If necessary.)



Note: : In the following examples, the SIM is for Cingular.

APN = isp.cingular

Username = ISP@CINGULARGPRS.COM

Password = CINGULAR1

bb. Reset the SA-G+ to factory defaults:

To restore the SA-G+ to factory defaults, send the following command:

AT&F<CR>

To write current config to memory, send the following command:

AT&W<CR>

To reset the SA-G+, send the following command:

AT\$RESET<CR>

cc. Configure the SA-G+ to Access the GPRS network.

To inform the SA-G+ of the proper APN, send the following command:

```
AT+CGDCONT=1,"IP","apn"<CR> (substitute the letters apn for  
the supplied apn.)
```

To inform the SA-G+ of the proper username and password, (if necessary) send the following command:

```
AT%CGPCO=1,"username,password"<CR> (substitute the correct  
username and password)
```

To configure the SA-G+ to enable auto GPRS registration, send the following command:

```
AT$AREG=2<CR>
```

Store the current configuration to memory, send the following command:

```
AT&W<CR>
```

Reset the SA-G+ by removing power or sending the command.

```
AT$RESET<CR>.
```

Verify GSM status by sending the following command:

```
AT+CREG?<CR>
```

If everything is working, you should receive one of two responses:

```
+CREG: 0,1 (GSM registered to home network)
```

OR

```
+CREG: 0,5 (GSM registered roaming.)
```

Verify GPRS status by sending the following command:

```
AT%CGREG?<CR>
```

If everything is working, you should receive one of two responses:

```
%CGREG: 0,1 (GPRS registered to home network)
```

Or

```
%CGREG: 0,5 (GPRS registered roaming.)
```

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



```
Enfora Com1 - HyperTerminal
File Edit View Call Transfer Help
[Icons]
AT&F
OK
AT&W
OK
AT-Command Interpreter ready
AT+CGDCONT=1,"IP","isp.cingular"
OK
AT%CGPCO=1,"ISP@CINGULARGPRS.COM,CINGULAR1"
OK
AT$AREG=2
OK
AT&W
OK
AT-Command Interpreter ready
AT+CREG?
+CREG: 0,1

OK
AT%CGREG?
%CGREG: 0, 1

OK
Connected 0:09:40 Auto detect 115200 8-N-1 SCROLL CAPS NUM Capture Print echo
```

Verify GPRS activation by sending the following command: AT\$NETIP?<CR>

If the response is non-zero, then everything is working. Skip to Step 10.

```
Enfora Com1 - HyperTerminal
File Edit View Call Transfer Help
[Icons]
AT%CGPCO=1,"ISP@CINGULARGPRS.COM,CINGULAR1"
OK
AT$AREG=2
OK
AT&W
OK
AT-Command Interpreter ready
AT+CREG?
+CREG: 0,1

OK
AT%CGREG?
%CGREG: 0, 1

OK
at$netip?
$NETIP: "166.170.006.159", "066.102.163.231", "066.102.163.232"

OK
at$cgeer
$cGEER: no PDP reject cause

OK
-
Connected 0:16:26 Auto detect 115200 8-N-1 SCROLL CAPS NUM Capture Print echo
```

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



If AT\$NETIP returns all zeros, send the following command: AT\$CGEER<CR>

There are three common responses:

- \$CGEER: no PDP reject cause (Everything should be working OK)
- \$CGEER: requested service option not subscribed (APN is incorrect or SIM has not been enabled for data mode.)
- \$CGEER: user authentication failed (username and/or password is incorrect.)
-

Configure the SA-G+ to access the Enfora Server.



Note: To configure the SA-G+ for server interoperability, several things have to be addressed.

- Most GPRS configurations are Mobile Originate only. The mobile SA-G+ must initiate a conversation with a remote server before the remote server can talk to the SA-G+.
- IP addresses are dynamically assigned and can change.
- Some IP addresses are NAT and are non-routable IP addresses.

These issues are addressed with the following configuration commands.

The examples will use the following information:

- Modem ID/name = "SAG_Test"
- Remote Server DNS address = apitest.enfora.com
- Remote Server IP port = 1721

Give the SA-G+ a unique name.

- Send the following command: AT\$MDMID="SAG_Test" This command, combined with the wakeup message, will allow the server to associate a Public IP address with a specific SA-G+ and create a window of opportunity where the server can send commands to the SA-G+

**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



Configure the SA-G+ to talk with a specific server.

- Send the following command: AT\$FRIEND=1,1,"apitest.enfora.com"

Set the port number

- Send the following command: AT\$UDPAPI=,1721

Enable periodic messages (wakeup) to be sent to the server every 60 seconds

- Send the following command: AT\$WAKEUP=1,1

A screenshot of a HyperTerminal window titled "Enfora Com1 - HyperTerminal". The window contains a series of AT commands and their responses. The commands are: AT\$MODID="SAG_TEST", AT\$FRIEND=1,1,"apitest.enfora.com", AT\$UDPAPI=,1721, and AT\$WAKEUP=1,1. Each command is followed by an "OK" response. The status bar at the bottom of the window shows "Connected 0:07:33", "Auto detect", "115200 8-N-1", and several function keys like SCROLL, CAPS, HELP, Capture, and Print echo.


```
AT$MODID="SAG_TEST"  
OK  
AT$FRIEND=1,1,"apitest.enfora.com "  
OK  
AT$UDPAPI=,1721  
OK  
AT$WAKEUP=1,1  
OK  
-
```

6 Verifying Server Connectivity




Note: For the following tests, Java Runtime must be installed on the computer. (To install Java Runtime, please visit the Java website here: <http://www.java.com/en/download/manual.jsp>)

6. Start Internet Explorer and enter the following URL:
<http://apitest.enfora.com/udpapp/>
7. Enter the name used in the MDMID command in the box. Select Connect.
8. Select the tab with the SA-G+ name. Within approximately 60 seconds the wakeup messages should be seen in the window.



**Enfora GSM1308 and
GSM1318
Quad-Band Spider®
SA-G+**



9. Enter the following command in the command/ data block: AT1
10. Select Write.
11. Verify that you see the following the SA-G+ response with Enfora, Inc. If so, you have successfully configured the SA-G+ to talk with the server.

7 Tech Support

For problems stemming from your network access, contact your GSM/GPRS carrier service. For technical support and customer service dealing with the modem itself, contact the company where you purchased the product. If you purchased the product directly from Enfora, visit the Support and Resources page on the Enfora website: <http://www.enfora.com>.